

EXPLOSIONSZEICHNUNG



KBS Gastrotechnik GmbH – Schoßbergstraße 26 – 65201 Wiesbaden

Type	SKU Number	Model Name	Parent Product
Spare Part	1.03.03030029-00	S100-charging pile - EU	S100
Spare Part	2.01.01030069-01	LSE LiDAR	S100
Spare Part	2.01.01030071-12	USB_LORA V1.2	S100
Spare Part	2.01.01030167-00	S100 Industrial Control Computer	S100
Spare Part	2.01.01030184-10	U_SIM Card Adapter Board V1.0	S100
Spare Part	2.01.01030197-10	RK3288_UIB_DUAL_LVDS V1.0	S100
Spare Part	2.01.01030207-01	Chassis Control Board V1.2- Industrial 48V	S100
Spare Part	2.01.02020234-03	W3_11.6-inch Touchscreen Line	S100
Spare Part	2.01.02020429-01	T5&T6 electrostatic chain	S100
Spare Part	2.01.02020435-00	Emergency Stop Switch Component - 2NC	S100
Spare Part	2.01.02020952-01	Front Light Strip	S100
Spare Part	2.01.02020958-01	Rear Light Strip	S100
Spare Part	2.01.02020964-00	LVDS Line	S100
Spare Part	2.01.03020003-16	RT1052 Image Positioning Module component V1.4	S100
Spare Part	2.01.03020009-00	ESP_WIFI Module with USB Interface Component V1.1	S100
Spare Part	2.02.02010009-00	Hub Motor with Magnetic Encoder V5.7	S100
Spare Part	3.01.09040014-00	29.2V/8A Manual Charger AC Line - EU	S100
Spare Part	3.01.09040015-00	29.2V/8A Manual Charger AC Line - AUS	S100
Spare Part	3.01.09040016-00	29.2V/8A Manual Charger AC Line - UK	S100
Spare Part	3.01.09040017-00	29.2V/8A Manual Charger AC Line - AUS	S100
Spare Part	3.01.09040028-00	29.2V/8A Manual Charger AC Line - Kr	S100
Spare Part	3.01.09040029-00	29.2V/8A Manual Charger AC Line - JP	S100
Spare Part	3.01.11020010-60	EyeCore Stereo Vision V6 (EMC Version)	S100
Spare Part	3.01.11020022-00	iHawk100R1 Stereo Vision	S100
Spare Part	3.01.12020012-00	10.1-inch Screen Display	S100
Spare Part	3.01.14050013-00	Power Control Switch	S100
Spare Part	3.01.17010062-00	54.6V 5A Charger	S100
Spare Part	3.01.19010001-00	Battery	S100
Spare Part	3.01.20020008-00	LTE 4G Module	S100
Spare Part	3.01.21030001-00	3G Module Antenna	S100
Spare Part	3.01.21030002-00	WiFi Antenna	S100
Spare Part	3.01.21030005-00	2.4G Antenna	S100
Spare Part	3.01.21030006-00	LoRa Stick Antenna	S100
Spare Part	3.02.02070010-00	Universal wheel	S100
Spare Part	3.02.04010834-00	Power Cover	S100
Spare Part	3.02.04010837-02	Front Shell	S100
Spare Part	3.02.04010838-01	Display Back Shell	S100
Spare Part	3.02.04010839-02	Front Shell	S100
Spare Part	3.02.04130078-01	Battery Outer Casing	S100
Robot	S100-LS-TSV-SR-CN_M050C00	S100 Heavy Duty Robot	S100